



TECHNICAL DATA

MODEL	SKU	WATTS	LUMENS	BEAM ANGLE	DF	CRI	INPUT POWER	OPERATION TEMPERATURE	DIMENSION (LxWxH)	WIRE LENGTH
VT-44010	9898,9899,10010 10011,10012,10013		735LM	115°	>0.9	>70	AC: 220-240V 50Hz	-20°C to +45°C	104x21x92mm	20cm
VT-44020	10014,10015,10016 10017,10018,10019	20W	1620LM	115°	>0.9	>70	AC: 220-240V 50Hz	-20°C to +45°C	126.5x28x114mm	1M
VT-44030	10020,10021,10022 10023,10024,10025	30W	2505LM	115°	>0.9	>70	AC: 220-240V 50Hz	-20°C to +45°C	164x29x139mm	1M
VT-44050	10026	50W	4270LM	115°	>0.9	>70	AC: 220-240V 50Hz	-20°C to +45°C	183x29x169mm	1M
VT-44200	10027,10028, 10029,10030	200W	17540LM	115°	>0.9	>70	AC: 220-240V 50Hz	-20°C to +45°C	405x36x326mm	1M
VT-44300	10031,10032 10033,10034	300W	26390LM	115°	>0.9	>70	AC: 220-240V 50Hz	-20°C to +45°C	496x49x445mm	1M

*This product contains a light source of energy efficiency class<F>,where <F> shall be replaced by the energy class of the contained light source.

INTRODUCTION & WARRANTY

Thank you for selecting and buying V-TAC product. V-TAC will serve you the best. Please read these instructions carefully before starting the installing and keep this manual handy for future reference. If you have any another query, please contact our dealer or local vendor from whom you have purchased the product. They are trained and ready to serve you at the best. The warranty is valid for 5 years from the date of purchase. The warranty does not apply to damage caused by incorrect installation or abnormal wear and tear. The company gives no warranty against damage to any surface due to incorrect removal and installation of the product. The products are suitable for 10-12 Hours Daily operation. Usage of product for 24 Hours a day would void the warranty. This product is warranted for manufacturing defects only.



WARNING

- Please make sure to turn off the power before starting the installation.
- Installation must be performed by a gualified electrician.
- The light source of this luminaire is not replaceable, when the light source reaches its end of life the whole luminaire should be replaced.
- If the external flexible cable or cord of this luminaire is damaged, it shall be exclusively replaced by
- the manufacturer or his service agent or a similar qualified person in order to avoid a hazard. 12-1-11 .
- Replace any cracked protective shield. **1**−− 1ME
- Minimum distance from lighted objects 1m.
- Terminal block not included.
- Proper grounding should be ensured throughout the installation.

NOTE: To reduce the risk of strangulation the flexible wiring connected to this luminaire shall be effectively fixed to the wall if the wiring is within arm's reach.





This marking indicates that this product should not be disposed of with other household wastes.




Caution, risk of electric shock.

INSTALLATION DIAGRAM








0 N


++

0 L 💷

Y./Grn. 💶 🕀

Brown









MANUAL QR CODE Please scan the QR code to access the manual in multiple languages.

INSTALLATION INSTRUCTION

• DO NOT USE IN AREAS WITH LIMITED VENTILATION OR OUTSIDE THE RATED AMBIENT TEMPERA-TURE RANGE. *CONNECT WITH WATERPROOF CABLE HOUSE ONLY. *ENSURE ELECTRICITY IS SWITCH OFF BEFORE INSTALLATION.

• Please do not mount to a surface that is prone to vibrations.*


Remove the screw and the bracket afterward. (Figure 1)Before drilling, mark the hole position for fixing the bracket onto the wall (Screw not supplied). (Figure 2)

• Screw the retaining bracket to the wall with a suitable quantity of screws. (Figure 3)

• Mount the bracket back to the fixture. Adjust the floodlight according to the desired position. Tighten the screw. (Figure 4) Connect your main cable (H05RN-F3G1.0mm2 Recommended) with the input lead of our product through the waterproof junction box. Note, the line (-) of the lead. (Figure 5) (Need to use the junction box of IP65 or above, ensure to tighten the waterproof screw) Switch on the power to make sure if the product Is working.

DISMANTLING INSTRUCTIONS

(For Market surveillance team only)





IN CASE OF ANY QUERY/ISSUE WITH THE PRODUCT, PLEASE REACH OUT TO US AT: SUPPORT@V-TAC.EU FOR MORE PRODUCTS RANGE, INQUIRY PLEASE CONTACT OUR DISTRIBUTOR OR NEAREST DEALERS. V-TAC EUROPE LTD. BULGARIA, PLOVDIV 4000, BUL.L.KARAVELOW 9B